



* The Clear Runout Area is additional clear-zone space that is needed because a portion of the Required Clear Zone (shaded area) falls on a non-recoverable slope. The width of the Clear Runout Area is equal to that portion of the Clear Zone Distance that is located on the non-recoverable slope.

FIGURE 3.2 Example of a parallel foreslope design